



Full Coverage Ionizing Blower

MODEL 6460

Using patented IsoStat technology¹, the Model 6460 blower guarantees consistent static control coverage. With its overhead mounting system, the Model 6460 doesn't compromise valuable space on the workbench, allowing for complete neutralization of static charge. The blower's steady-state DC ion emission enables fast discharge with low airflow, providing a more comfortable work environment for operators. Emitter points are placed behind the fan to eliminate field-induced charge and to ensure a homogeneous mixture of ionized air. Also featured are open-cell foam filters on the fan intakes, protecting the internal components from environmental contamination.





Features and Benefits

- Patented IsoStat® technology with steady-state DC ion emission
- Self balanced; no calibration needed
- Alarm relay closure circuitry
- Alarm notification communicates operational failure to a remote location
- Multicolor LED indicator
- Visual performance indicator: green for normal operation and red signals an operational failure alarm
- Two sizes: 32 inches with two fans, or 44 inches with three fans
- Multiple dimensions for flexibility in various manufacturing environments
- Patented Auto-Clean System
- Reduces manual emitter point cleanings

¹. U.S. Patent No. 5,055,963



Specifications

Full Coverage Ionizing Blower Model 6460	
Input power	100-240 VAC, 50/60 Hz, 30 watts max.
Indicators	Multicolor LED: power on green, operational failure red
Controls	Power/fan speed rocker switch (high/off/low settings)
Ion emission	IsoStat technology, steady-state DC
Emitter points	0.012" diameter tungsten wire, internally shielded
Ion balance	Better than ± 20 volts at 24" (62 cm); measurements taken at high fan speed <i>Tested in accordance with ANSI/ESD STM3.1-2000</i>
Coverage area	32 inch length: 2 x 3 feet 44 inch length: 2 x 4 feet typical, directly under blower
Discharge time	<8 seconds directly under each fanstack at 24 inches <i>Tested in accordance with ANSI/ESD STM3.1-2000</i>
Airflow volume	114 CFM maximum, per fan, free-air typical
Air filters	Replacable open-cell foam
Audible noise	58 dB (measurements taken at high fan speed)
Mounting	Four eyebolts and 1 1/8" S-hooks provided
Chassis	Aluminum with epoxy-polyester powder coat
Operating environment	Temperature: 50–95°F (10–35°C) Humidity: 20–55% RH (non-condensing)
Dimensions	3.6H x 6W x 32 or 44L inches (10.16H x 15.4W x 81.3 or 111.76L cm)
Weight	32 inch length: 8 lb (3.6 kg) 44 inch length: 10 lb (4.5 kg)
Warranty	2 year limited warranty
Certifications	   

Auto-Clean System

The Auto-Clean System¹ features a brush mechanism that sweeps the emitter points when the blower is turned off and on, allowing the Model 6460 to always perform at optimum ion output and balance. During operation of the fan, the brush automatically retracts to prevent emitter point wear. The Auto-Clean System brush will extend as the fan slows to a stop. Ion recommends activating the Auto-Clean System at least once a week. Cleaning schedules will vary depending on environmental conditions and application requirements. This automated feature results in reduced operation costs due to lower maintenance.



Ion's patented Auto-Clean System significantly reduces the need for manual cleaning

Patented IsoStat Technology

Ion's patented IsoStat technology is the first balancing technology for ionizers to guarantee intrinsically balanced ionization and elimination of complicated feedback circuits. IsoStat is based on a law of physics, Conservation of Charge, which states that charge cannot be created or destroyed in an isolated system. By isolating the ionizer's emitter points from ground, IsoStat ensures equal numbers of positive and negative ions. Characteristics of IsoStat ionizers include:

- Ionizers never need calibration and require very little maintenance
- Small size and operation without grounding wires

Ordering Information

91-6460-32	32" blower with Auto-Clean System
91-6460-44	44" blower with Auto-Clean System
31-2107	Replacement air filters (qty 10)
25-20660	IEC power cable, US plug, 8.2 ft. (2.5m)
25-20710	IEC power cable, UK plug, 8.2 ft. (2.5m)
25-20735	IEC power cable, German Schuko plug, 8.2 ft. (2.5m)
25-20750	IEC power cable (China plug), 8.2 ft. (2.5m)



1750 North Loop Road, Alameda, CA 94502
Tel: 510.217.0600 or 800.367.2452
Fax: 510.217.0484
info@ion.com, www.ion.com

DS-6460 - Ver. 3
© 2006 Ion Systems, Inc.
All rights reserved.

1. U.S. Patent No. 5,768,087